

## Sign with Built-In Aerial

In our "Above the Counter" loop kit (see page 7) the aerial is built into the blue loop sign.

The aerial transmits a magnetic field when connected to the HLD2 (see page 12), enabling the telecoil in a hearing aid to receive a signal from drivers.

The aerial should be positioned within 300mm from the user's hearing aid; it can be fixed in place using double sided tape, cable ties, or its stand (see page 14) on top of a flat surface.



### Physical Data:

Dimensions	Height - 205mm (8.07") Width - 205mm (8.07") Depth - 5.4mm (0.21") Connection cable length - 2m (78.74")
Weight	200g (0.44lbs)
Construction	Various
Finish	Various

### Product Code:

Sign with Built-in Aerial	IL-AE97-00
---------------------------	------------