

Aerial

Hearing loop aerial for use with our "Under the Counter" loop kit, which is fixed under desks or counters.

When connected to the HLD2 (see page 12), it transmits a magnetic field which enables the telecoil in the hearing aid to receive a signal from our hearing loop driver.

Position the aerial within 1.5m of the user's hearing aid and fixed in place using self adhesive clips, P-clips or hot glue. It is flexible and can be moulded into your desired shape.



Physical Data:

Dimensions	Can be moulded on site to required size/ shape by installers
Weight	100g (0.22lbs)
Construction	Copper Wire with Black Protective Covering
Finish	Black PVC

Product Code:

Aerial	IL-AE99
--------	---------